

COMPATIBILITY CHART

CITY MULTI®	
PMFY-NMBU	(E) NO (ER5) OK (After April 2012)
PEFY-NMU	(NMU-E) NO (After April 2012)
PEFY-NMAU	(E) NO (E2) OK (E3) OK (After April 2012)
PEFY-NMHSU	(E) OK (After Oct 2015)
PEFY-NMHU	(E) NO (E2) OK (After April 2012)
PEFY-NMLU	(E) NO
PEFY-NMSU	(E) NO (ER2) OK (After June 2012)
PLFY-NAMU	(A) NO (E) NO
PLFY-NBMU	(E) NO (ER2) OK (After April 2012)
PLFY-NCMU	(E) NO (ER4) OK (After June 2012)
PLFY-NFMU	(E) YES
PLFY-NLMU	(E) NO
PCFY-VKM	NO
PCFY-NGMU	(E) NO
PCFY-NKMU	(E) NO (E.TH) NO (ER1.TH) OK (After June 2012)
PFFY-NEMU	(E) OK (After April 2012)
PFFY-NRMU	(E) OK (After April 2012)
PVfy-E00	(A) OK (B) OK (After April 2012)
PVfy-NAMU	(E) OK (After April 2012)
PKFY-NAMU	(E) NO
PKFY-NFMU	(E) NO
PKFY-NGMU	(E) NO
PKFY-NBMU	(E) NO (E2) OK (After April 2012) (E2R1) OK (After April 2012)
PKFY-NHMU	(E) NO (E2) OK (After May 2012)
PKFY-NKMU	(E) NO (E2) OK (After June 2012) (E2.TH) ADPT (After June 2012)

P-Series	
PCA	(GA) NO (KA) OK (KA4) OK (KA4.TH) OK (KA6) OK (KA7) OK (After April 2012)
PEA	(AA) NO (AA4) OK (AA4R1.TH) OK (AA6) OK (After April 2012)
PEAD	(AA) NO (AA4) OK (AA5) OK (AA7) OK
PKA	(FA) NO (GA) NO (HA) NO (HAL) NO (HA4) OK (HA6) OK (HA7) OK (KA) NO (KA4) OK (KA6) OK (KA7) OK
PLA	(AA) NO (BA) NO (BA-1) NO (BA4) NO (BA6) NO (EA7) OK
PVA	(AA4) OK (AA7) OK

M-Series	
MFZ-KA	OK
MFZ-KJ	OK
MSZ/Y-A	NO
MSZ/Y-D	(NA) OK (NA-8) OK
MS-WA	NO
MSZ-FD	NO
MSZ-FE	09, 12 (NA) OK 09, 12 (NA-8) OK 18 (NA) OK
MSZ-EF	OK
MSZ/Y-GE	06 to 18 (NA) NO (NA-8) OK (NA-9) OK 24 (NA) OK
MSZ/Y-GL	OK
MSZ/Y-GS	OK
MSZ-FH	OK
MSZ-FS	OK
MSZ-HE	NO
MSZ-HM	OK
MSY-HM	NO
MVZ	(AA4) OK (AA7) OK
SVZ-KP	OK
SEZ-KD	(NA) OK (NA4) OK
SLZ-KA	OK
SLZ-KF	OK
MLZ-KP	OK
MSZ-JP	OK
MSZ-WR	OK

LEGEND

OK = Compatible

NO = Not compatible

ADPT = Install IT signal adapter PAC-IT51AD-E or PAC-IT52AD-E for compatibility

1340 Satellite Boulevard, Suwanee, GA 30024
Toll Free: 800-433-4822 www.mehvac.com